


Assembly Instructions



ASSEMBLY RATING


The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY

DIFFICULT

Tools Required For Assembly:

Allen Wrench




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List

Hardware List



#1 x 1pc
Table Top




#2 x 1pc
Connect Shelf



#3 x 6pcs
ARC Leg



#4 x 1pc
Round Connect Panel



#5 x 1pc
Foot Base



#A x 6pcs
Bolt Ø5/16" x 1-3/8"



#B x 18pcs
Bolt Ø5/16" x 2"



#C x 24pcs
Lock Washer Ø5/16"



#D x 24pcs
Flat Washer Ø5/16"




#E x 1pc
Allen Wrench M4




#B x 6pcs
#C x 6pcs
#D x 6pcs

1. Prepare 6 bolt assemblies by first inserting a lock washer (#C) onto the bolt (#B) then a flat washer (#D).
2. Align the arc legs (#3) to the round connect panel (#4), then insert the bolts and secure.



#B x 12pcs
#C x 12pcs
#D x 12pcs


1. Prepare 12 bolt assemblies by first inserting a lock washer (#C) onto the bolt (#B) then a flat washer (#D) onto that same bolt (#B).
2. Align the foot base (#5) to the holes along the bottom of the legs, then insert the bolts and secure.





#3


Remove the connect shelf (#2) from the table top (#1) by using the Allen wrench and turning left.



#4




#A x 6pcs
#C x 6pcs
#D x 6pcs

1. Prepare 6 bolt assemblies by first inserting a lock washer (#C) onto the bolt (#A) then a flat washer (#D) onto that same bolt (#A).
2. Align the connecting shelf (#2) to the holes along the top of the legs, then insert the bolts and secure.





1. Prepare 6 bolt assemblies by first inserting a lock washer (#B) onto the bolt (#A) then a flat washer (#C) onto that same bolt (#A).
2. Align the connecting shelf (#2) to the holes along the table top (#1), then insert the bolts and secure.



ASSEMBLY IS COMPLETED