








PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS
ITEM NO. / ARTICLE NO. / ARTICULO NO : S546-146
DESCRIPTION / DESCRIPCIÓN : SIDEBORD / BUFFET / APARADOR

⚠ WARNING

Children have died from furniture tip-over. To reduce the risk of furniture tip-over:

- ALWAYS install tip-over restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



A

- x1 Sideboard
- x1 Buffet
- x1 Aparador

B

- x2 Bun Foot *
- x2 Pied en forme d'oignon
- x2 Pata redonda

C

- x2 Bun Foot With levelers *
- x2 Pied en forme d'oignon
- x2 Pata redonda

D

- x1 Center leg *
- x1 Pattes centrales
- x1 Patas centrales



E

- x1 Furniture Tipping Restraint
- x1 Systeme antibasculement
- x1 Control para evitar vulcos

* Replaceable Part

ASSEMBLY INSTRUCTION / NOTICE DE MONTAGE/ INSTRUCCIONES DE MONTAJE

ITEM NO. / ARTICLE NO. / ARTICULO NO : S546-146


DESCRIPTION / DESCRIPCIÓN : SIDEBORD / BUFFET / APARADOR

⚠ WARNING






Children have died from furniture tip-over. To reduce the risk of furniture tip-over:

- ALWAYS install tip-over restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



Bun Foot Carton
Boîte des pieds en forme
Caja de las patas redondas



* Replaceable Part


REPLACEABLE PART / PARTIE REMPLACABLE / PARTE REEMPLAZABLE
 ITEM NO. / ARTICLE NO. / ARTICULO NO : S546-146
 DESCRIPTION / DESCRIPCIÓN : SIDEBORD/ BUFFET/ APARADOR

WARNING


Children have died from furniture tip-over. To reduce the risk of furniture tip-over:

- ALWAYS install tip-over restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!




TIRADOR y Tornillo
 POIGNÉE et vis
 x4 RS546-146-KNOB - Knob with Screw




x2 RS546 - 010 - PULL- Pull with Screw
 Tirer et vis
 Tira y Tornillo




x 2 COMGLIDE 12-45 Glide 12inch 45mm
 Glissière
 Carril de deslizamiento



x2 RS546-146-FOOT-Bun Foot
 Pied en forme d'oignon
 Pata redonda




x2 RS546-146-FOOT1-Bun Foot With levelers
 Pied en forme d'oignon et Patin réglable
 Pata redonda y Nivelador




x2 RS546-146-SHELF- Wood Shelf
 étagère
 estante




x8 RS546-146-SUP-Shelf supports
 Supports Pour Tablette
 Soporte De Las Repisas



x 4 RS546-146-CATCH-Door Catch
 Catch de aimant
 Captura de imán



x1 RS546-146-TRAY- Silverware Tray
 Plateau
 Bandeja



x8 RS546-146-HINGE-Door Hinge
 Charnière de porte
 Bisagra de la puerta



x1 RS546-146-LEG- Center leg
 Pattes centrales
 Patas centrales

* Replaceable Part