
# **COSTWAY**®



# **USER'S MANUAL ICE MAKER EP24525US**

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

## Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

# **Follow Costway**

Visit us: www.costway.com












# **Contact Us!**

# Do NOT return this item.

Contact our friendly customer service department for help first.



# **Before You Start**



A Retain instructions for future reference.

Seperate and count all parts and hardware.

Read through each step carefully and follow the proper order.

Me recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

Always place the product on a flat, steady and stable surface.

⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.



# TABLE OF CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	4
PREPARING YOUR ICE MAKER FOR USE	
IMPORTANT SAFETY TIPS	5-6
GETTING TO KNOW YOUR UNIT	7
OPERATING PROCEDURES & MAINTENANCE	
UNPACKING YOUR ICE MAKER	7
CONNECTING YOUR ICE MAKER	8
CLEANING AND MAINTAINING YOUR ICE MAKER	8-9
USING YOUR ICE MAKER	10
TROUBLESHOOTING	11
TECHNICAL PARAMETERS & CIRCUIT DIAGRAM	12

#### IMPORTANT SAFETY INSTRUCTIONS

Your safety and the safety of others are very important.

We have provided many important safety messages manual and your appliance. Always read and obey all safety messages.

This is the safety alert symbol:



All safety messages will follow the safety alert symbol and the word "DANGER" or "WARNING".

## **DANGER**

#### **WARNING**

These words mean:

You can be killed or seriously injured if you don't immediate follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

When using electrical appliances, basic safety precautions should be followed to reduce the risk of fire, electric shock, and injury to persons or property. Read all instructions before using any

#### **IMPORTANT SAFETY TIPS**

appliance.


- Do not operate this, or any other appliance with a damaged cord.
   Connect to properly polarized outlets only. No other appliance should be plugged into the same outlet. Be sure that the plug is fully inserted into the receptacle.
- Do not run the power cord over carpeting or other heat insulators. Do not cover the cord. Keep cord away from traffic areas, and do not submerge in water.
- We do not recommend the use of an extension cord, as it may overheat and become a risk of fire. If you must use an extension cord, use No.14 AWG minimum size and rated no less than 1875 watts.
- Unplug the ice maker before cleaning or making any repairs or servicing.
- Exercise caution and use reasonable supervision when appliance is used near children.
- Do not use your ice-maker outdoors. Place the ice-maker away from direct sunlight and

make sure that there is at least 6 inches of space between the back of your unit and wall. Keep a minimum distance of 6 inches on each side of your unit free.

- Do not use other liquid to make the ice-cube other than water.
- Do not clean your ice maker with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not tip over.
- If the ice maker is brought in from outside in wintertime, give it a few hours to warm up to room temperature before plugging it in.

**WARNING**: This appliance must be earthed.

 DANGER – Risk Of Fire or Explosion. Flammable Refrigerant Used. Do Not Use Mechanical Devices To Defrost Ice Maker. Do Not Puncture Refrigerant Tubing.



- CAUTION Risk Of Fire Or Explosion. Flammable Refrigerant Used. Consult Repair Manual/Owner's Guide Before Attempting To Install or Service This Product. All Safety Precautions Must be Followed.
- CAUTION Risk Of Fire Or Explosion. Dispose Of Property In Accordance With Federal Or Local Regulations. Flammable Refrigerant Used .
- CAUTION-Risk Of Fire Or Explosion Due To Puncture Of Refrigerant Tubing; Follow Handling Instructions Carefully. Flammable Refrigerant Used.
- The ice maker should be installed in accordance with the safety standard for Refrigeration Systems, ASHRAE15. The ice maker shall not be installed in corridors or hallways of public buildings.
- If the unit is with problem need to be maintained, that replacing with like components and that servicing shall be done by factory authorized service personnel, so as to minimize the risk of possible ignition due to incorrect parts or improper service.

#### IMPORTANT:


The wires in this mains lead are colored in accordance with the following code:

Green or Green with a strip yellow: Grounding White: Neutral Black: Live

To avoid a hazard due to instability of the appliance, it must be placed at a even or flat surface.

# **GETTING TO KNOW YOUR UNIT**

- 1. Water reservoir cover
- 2. Unit top cover
- 3. Water separator pipe
- 4. Evaporator
- 5. Ice basket
- 6. Ice scoop
- 7. Transparent window
- 8. Control Panel:
  - C. LCD Display area
- 1. Ambient temp and ice making countdown symbol: when display show <M>, ice making countdown, when display show <°F>, means ambient temp.
- 2. Ice making and Ice harvest symbol: when the symbol is running, the unit is making ice cube ,when the symbol flash, the unit is ice harvest.
  - 3. ON/OFF symbol.
  - 4. Error code E1-Ambient temp senor breakdown.E2-refrigerating tube sensor breakdown
  - 5. Lack water warning symbol.
  - 6. Ice full warning symbol.
- 7. Time setting display area. When show <H>,timer unit ON/OFF, when show <M>,setting ice making time.
  - D. Ice making and timer reduce.
  - E. ice making and timer increase.
- 9. Hot Air Outlet
- 10. Water draining port: To draining out the water from unit.



#### **OPERATING PROCEDURES & MAINTENANCE**

#### **UNPACKING YOUR ICE MAKER**

- 1. Remove the exterior and interior packaging. Check that ice basket and ice scoop is included. If any parts are missing, please contact our customer service.
- 2. Clean the interior with lukewarm water and a soft cloth. Take out the ice basket and clean it
- 3. Find a location for your ice maker that is protected from direct sunlight and other sources of heat (i.e.: stove, furnace, radiator). Place the ice maker on a level surface. Maker sure that there is at least 6 inches of space between the back and sides of your ice maker and the wall.
- 4. Allow one hour for the refrigerant fluid to settle before plugging ice maker in.
- 5. The appliance must be positioned so that the plug is accessible.

WARNING: fill with potable water only.

#### **CONNECTING YOUR ICE MAKER**

## **DANGER**

- \* Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged please call our customer service.
- 1. This unit should be properly grounded for your safety. The power cord of this appliance is equipped with a three-prong plug which mates with standard three prong wall outlets to minimize the possibility of electric shock.
- 2. Plug your appliance into an exclusive, properly installed, grounded wall outlet. Do not under any circumstances, cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified electrician.
- 3. This appliance requires a standard 110-120volt, 60Hz electrical outlet with three-prong ground.

#### **CLEANING AND MAINTAINING YOUR ICE MAKER**

#### Before using your ice maker, it is strongly recommended to clean it thoroughly.


- 1. Take out the ice basket.
- 2. Clean the interior with diluted detergent, warm water and a soft cloth.
- 3. Then use the water to rinse the inside parts, and drain out the water from the draining port by unplugging the drain cap on the back.
- 4. The outside of the ice maker should be cleaned regularly with a mild detergent solution and warm water.
- 5. Dry the interior and exterior with a soft cloth.
- 6. When the machine is not in use for a long time, open the water drain cap to drain water completely out from the water reservoir.

After using your ice maker for a long time, we also suggest you should clean



**your unit.** Especially to the water separator pipe and the wate filters, you must clean them periodically.

1. If the water separator pipe is blocked and there is no water flowing down when you listen the compressor and the water pump inside are still working, please turn off the unit first and disassemble this pipe down, and clean it. Clean the each hole on the pipe wall displayed in following picture. After cleaning, install back the water separator pipe and be sure the right terminal of the pipe connect to the silicone pipe well and as original.




- 2. For both of the water tank and the big water reservoir, clean them with diluted detergent, warm water and a soft cloth. Then use the water to rinse the inside, and drain out the water from the draining port by unplugging the drain cap on the back. It will help you keep the unit and ice-cube hygienicly, and also make the unit work normally.
- 3. When cleaning, if find that the ice cube left on the evaporator and can not be taken out easily, you can turn on the unit to let the unit enter the ice making process, then press "ON/OFF" button for more than 5 seconds to let the unit start ice harvest process to melt the ice cube. It will help you remove the hard ice cube.

# How to drain out the water from the internal tank and big water reservoir completely


Because the water in the big water reservoir is stop to drain port by the water valave, if you want to drain away all the water, please plug on the unit and but don't start the unit, then remove the drain port cap at the back. Wait some minutes, all of the water will flow out.

## **USING YOUR ICE MAKER**

Operation panel and display area



Remove the cover of the water reservoir and pour potable water into water reservoir.
 And be sure to keep water level below the max. level with FULL mark displayed in following picture. Then move back the cover at once to avoid foreign matter enter.



Warning: Do not pour the water into the internal water tank located underneath the ice basket. This tank is not big enough and will effect the ice making performance.

- 2. When you plug the unit, the power symbol > will flash. Press the <ON/OFF>button, the unit will start making ice cube, ice making symbol > will keep running. The left up corner of display area will show the ambient temp,i.e:80°F means the ambient temp is 80°F. After several mins, this area will show flash number, the ice making will countdown,i.e:10M means the ice making will finish 10 mins later.

Remark: The ice making cycle lasts about 13 to 25 minutes, depending on the ambient temperature. And for the first time, according to the initial water temperature, ice-making last time



will be a little longer. In the extreme hot room temperature, ice-making time may be Vary a lot, but it will not exceed35minutes.

If you think the ice cube is not thick enough, during ice making,press the<+>and<->to set the ice making lead time. Press one time and the ice making cycle will in crease or Reduce one min,6minmost.This can only start from the new cycle.


4. When Ice Full symbol< is on, the unit will stop, take out the ice cube inside, the unit will start working again.

If press the button<ON/OFF>more than 5s,when the ice maker is working, the unit will start harvest. Press button<ON/OFF>,the unit will turn off.

Timer setting. Unit on timer setting, When the unit is working, timer setting the unit off. Unit off Timer setting, When the unit is off, timer the unit on.

Press the<TIMER>button,the display will show<1H>,and then press<+>and<->to set the time.During the setting,the H is flash,after 5s,the H will keep on and unit will in your Timer setting..

5. Water Drain: take off the drain plug capon the back of unit, take out the silicon plug, then drain the water inside. It is better that exchange water every 24hours and clean unit every 3days.



#### Warning

- A, make sure the water tank, water filter and the water separator pipe is not blocked, clean them
- B. The water temp will effect the ice making capacity. The lower temp, the more ice cube produce.
- C, The cooler ambient temp, the more ice cube produce.
- D, always use good quality water to make sure the pump work well.Bad quality water will cause pump noise,but doesn't effect the unit working.
- E. The compressor restart 3mins later if you turn off the unit.

# TROUBLESHOOTING


PROBLEM	POSSIBLE CAUSE	SOLUTION	
< > is on	Lack of water	Turn off the unit and add water to <full>level, then re-start the unit.</full>	
< >is on	Too much ice cube in the basket	Remove the ice cube in the basket	
The water reservoir has water,but<	The inlet solenoid valve breakdown	Need the technical service person to maintain	
<b><e1></e1></b> is on	Ambient temp sensor breakdown	The unit can still work, change a new sensor	
<b><e2></e2></b> is on	Refrigerating tube sensor breakdown	The unit can still work, change a new sensor	
No water in the water	The holes are blocked	Use slim wire to prick each hole, till The water can flow out easily.	
Separator pipe	Water filter block	Clean the water filter	
Ice cube thick and cann't Drop down	Ice making cycle too long	Press <->to reduce the ice making time.	
	Ambient temp too high	Move the unit to cool place	
Ice cube thin	Water temp too high	The water temp should be no more morethan25°C (77°F).	
	Ice making short	Press<+>to increase the ice making Time.	
Unit work but no ice cube	Ambienttempishighorthe watertempishigh	Move the unit to somewhere ambier Temp lower than 30 °C (86 °F ), fill coowater.	
	Refrigerant system leakage	Need the technical service person to maintain	
	Refrigerant systemblock	Need the technical service person to maintain	

## TECHNICAL PARAMETERS & CIRCUIT DIAGRAM

#### TECHNICAL PARAMETERS

Model	EP24525US
Protection Type	I
Power	115V/60Hz
Ice Making Current	1.6A
Ice Harvest Current	2.6A
Refrigerant	R600a 1.13Oz/32g
Design Pressure	
High Side	260Psig
Low Side	88Psig
Net Weight	11kg
Enclosure	Stainless

#### **CIRCUIT DIAGRAM**



# Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us! We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

**US office: Fontana, California** 

**UK office: Ipswich** 



- \* Reward Points
- \* Exclusive Customer Service
- \* Personalized Recommendations
- \* Permanent Shopping Cart
- \* Order History

# 5 Star Rating 公公公公公

We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.





