## P- 1

ITEM : TY320925

FUNCTION — P- 2

- ● POWER
- ● KEYBOARD
- ● VOLUME + -
- ● ACC VOLUME + -
- ● LED DISPLAY
- ● TONE DIVERSION
- ● TONE/RHYTHM + -
- ● RHYTHM
- ● RHYTHM DIVERSION
- ● FILL-IN

- ● STOP
- ● TEMPO
- ● SOUND EFFECT
- ● CHORD
- ● SYNC
- ● DRUM
- ● RECORD/PLAY
- ● DEMO
- ● LEARN

USER MANUEL — P- 3

① POWER
Power→on: into play "keyboard" mode(photo1/2)

② VOLUME
Using "volume +-" up or down the volume
"ACC volume+ -"up or down the Rhythm volume(photo3/4)

③ TONE
Press"Tone Page", can up or down the Tone by "Tone/Rhythm +-"
(photo6/7)

④ RHYTHM
1.Press"Rhythm",select "01-05" Rhythm.(photo8)
2.Press"Rhythm Page" can change Rhythm to "06-10" (photo9)
3.Under Rhythm Mode,can up or down the Rhythm by"Tone/Rhythm+-"
(photo7)
4.Under Rhythm mode,press "Fill-in" to insert a transition Rhythm.
(photo10)
● Press Stop to close the Play Mode

⑤ TEMPO
Press "Tempo+-" to fast or slow the Tempo.(photo12)

⑥ SOUND EFFECT
Volume Control insert the Keyboard(Sustain,Vibrato)
1.Press "SUSTAIN" into the keyboard sound with sustain effects.
(photo13)
2.Press "vibrato" into the keyboard sound with Vibrato effects.
(photo13)
● Press again to close "SUSTAIN"/"VIBRATO" effects.

USER MANUEL — P- 4

⑦ CHORD
The keyboard insert single and Finger Chord system.You should select
the Rhythm before using it.
1.To select the Rhythm what you want to play by press"Rhythm" btn.
(photo8)
2.Into Chord MOde by press "SINGLE" or "FINGER" btn.(photo14)
3.To play the chord by press the left Chord area
4.The chord can play with the "SYNC" btn Function.(photo14/15)

⑧ DRUM
Press"Drum" change Piano to Drum function
to close "Drum"Function by press "Drum"again(photo16)

⑨ RECORD/PLAY
1.Press"Record" btn into Record Mode(photo17)
2.Record the musice what you play on the piano keyboard
3.Play what you Record by press "Play" btn
● Press Stop to close the Play Mode

⑩ DEMO
The keyboard insert 6 Demo Music.
"Demo One" to play a music,"Demo All"to play insert music one by one
(photo18)
● Play "STOP" to stop demo mode

⑪ LEARN MODE
Press "Learn" btn into the learning mode by press White Key.
(photo19)
● Press "STOP" to stop it.