


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Hammer

(Not Included)



**Philips
Screwdriver**

(Not Included)



**2 - Persons
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

Note :


Every cam lock bolt must have a cam lock connector in order to fasten the parts together.




cam bolt



cam lock




screwdriver




1

Screw the cam bolt into panel.




2

Insert the cam bolt into the bolt hole of joint panel.



3


Align the cam lock with its side opening (or arrow) pointing to cam bolt.




4

Turn the cam lock clockwise gently until it will not turn any more.


COFFEE TABLE




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS



HARDWARE




ACCESSORIES




GET READY

Please group boards as below.


O 1PC




P 1PC



Q 1PC




R 1PC



S 1PC




T 1PC




Drawer


A 1PC




C 1PC




D 1PC




E 1PC




F 1PC



G 1PC




J 1PC




K 1PC



L 1PC



M 1PC




H 2PCS



I 1PC



B 1PC



Body

N 1PC



Door

ASSEMBLY INSTRUCTIONS

Identifying Drawer Rails


Each drawer requires a set of 4 rails. Please review the below instructions to help identify the different rails. Left and right determined from the viewpoint of opening the drawer.

Right/Left Panel Rail:


(C-shaped frame)

Align the drawer rails horizontally, with the oval and round holes resting flat against a surface. Rotate as needed so the rollers are located on your right-hand side. If the roller is closer to the bottom corner, this is the RIGHT panel rail. If the roller is closer to the top corner, this is the LEFT panel rail.


Right Panel Rail




Left Panel Rail



Right Drawer Rail



Left Drawer Rail



Right/Left Drawer Rail:




(S-shaped frame)

Align the panel rails horizontally. Rotate as needed so the rollers are located on your right-hand side. If the roller faces away from you, this is the RIGHT drawer rail. If the roller faces towards you, this is the LEFT drawer rail.

When grouped together, the right drawer rail and right panel rail will interlock with rollers at opposite ends. Likewise for the left drawer and left panel rails.

1







Hardware ⑦ x 2 pcs Drawer Rails
Hardware ⑧ x 4 pcs



ASSEMBLY INSTRUCTIONS

1


- Part **O** x 1 pc
- Part **P** x 1 pc
- Part **Q** x 1 pc
- Part **R** x 1 pc
- Part **S** x 1 pc
- Part **T** x 1 pc
- Hardware **1** x 2 pcs
- Hardware **2** x 2 pcs
- Hardware **3** x 2 pcs (8x30)
- Hardware **4** x 4 pcs (5x20)
- Hardware **6** x 4 pcs



ASSEMBLY INSTRUCTIONS

2







Hardware ① x 14 pcs
Hardware ③ x 34 pcs (8x30)
Hardware ⑨ x 1 set



ASSEMBLY INSTRUCTIONS

3


- Hardware ① x 4 pcs
- Hardware ③ x 8 pcs (8x30)
- Hardware ⑦ x 2 pcs panel rails
- Hardware ⑧ x 4 pcs
- Accessory A2 x 1 set



ASSEMBLY INSTRUCTIONS

4


Part **A** x 1 pc
 Part **C** x 1 pc
 Part **D** x 1 pc
 Part **E** x 1 pc
 Part **F** x 1 pc
 Part **G** x 1 pc
 Hardware ② x 8 pcs



Front
 Top


5

Hardware ② x 4 pcs





Front
 Top

Part	J	x	1	pc
Part	K	x	1	pc
Part	L	x	1	pc
Part	M	x	1	pc




Part **H** x 2 pcs
Part **I** x 1 pc
Hardware **②** x 6 pcs



ASSEMBLY INSTRUCTIONS


8

Part **B** x 1 pc
Hardware **5** x 10 pcs



9



Accessory **A3** x 2 pcs (Lock)
Accessory **A4** x 3 pcs
Accessory **A5** x 20 pcs



ASSEMBLY INSTRUCTIONS



10

Part **N** x 1 pc
 Hardware **8** x 2 pcs
 Hardware **10** x 1 set
 Hardware **11** x 1 set



11

Accessory **A6** x 4 sets



ASSEMBLY INSTRUCTIONS

12

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

