


Item # : AF30KAR2D Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 25/12/2019(C)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.




- VIII. Drill may be needed for securing product to wall.


- IX. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment



Vertical
Via slots in the mounting
plate or via cam adjustment


Parts List



Hardware List

A		Ø8x30mm	Wooden dowel	18 pcs
B		Ø15x9mm	Cam lock	4 pcs
C		Ø15x11mm	Cam lock	11 pcs
D		Ø6x35mm	Cam bolt	15 pcs
E		Ø6x50	Bolt	6 pcs
F		M4	Hex Key	1 pc
G		Ø6x12mm	Bolt	16 pcs
H			Europe hinge	4 pcs
J		Ø3.5x14mm	Screw	24 pcs
K			Handle	3 pcs
L		Ø3x12mm	Screw	18 pcs
M		Ø4x32mm	Screw	5 pcs
N			Shelf support pin	8 pcs
P			Glue tube	1 pc
Q		Ø30mm	Sticker	15 pcs
R			Plastic wedge	12 pcs
S		Ø3x17mm	Screw	12 pcs
T		Ø4x12mm	Screw	1 pc
U		Ø4x25mm	Screw	1 pc
V			Plastic strap	1 pc
W			Nut	1 pc
X			Drawer slider	1 set


* Note: This piece comes preassembled for shipping purposes and must be disassembled to complete the desk assembly.



**Philips head screwdriver required for assembly
(not included)**


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wooden dowel (A) into parts (5,11,14) as per diagram.

Step 2




Insert wooden dowel (A) into parts (4,6) , secure cam bolt (D) into parts (1,16) with Philips head screwdrivers per diagram.

Step 3




Pick up the slider arm (X) and separate the slide Runner for the following steps. Extend the Slide Runner all the way forward, press the plastic release lever of the slider arm up and pull the Slide Runner Complete out .

Step 4




Using screw (L) attach Slider arm (X) to parts (4,6) with Philips head screwdriver as per diagram.

Step 5





Using screw (L) attach Slider bracket (X) to parts (13,15) with Philips head screwdriver as per diagram.

Step 6




Using bolt (E) attach part (11) to part (5) with hex key (F) as per diagram.

Step 7




Using cam lock(C) secure parts (4,6) to part (11) with Philips head screwdriver as per diagram.

Step 8




Put part (12) as per diagram.

Step 9




Using bolt (E) attach part (19) to parts (4,6) with hex key (F) as per diagram.

Step 10





Using bolt (G) attach parts (20) to part (19) with hex key (F) as per diagram.

Step 11






Put parts (9,10) as per diagram.

Step 12




Using cam lock (C) secure part (1) into parts (4,5,6) with Philips head screwdriver as per diagram.

Step 13




Using screw (S) secure plastic wedge (R) with Philips head screwdriver as per diagram.

Step 14




Using screw (L) attach handle (K) to part (16) with Philips head screwdriver as per diagram.

Step 15




Using screw (M) attach parts (13,15) to part (18) with Philips head screwdriver as per diagram.

Step 16





Put part (17) as per diagram.

Step 17




Using screw (M) attach part (18) to part (14) with Philips head screwdriver as per diagram.

Step 18




Using cam lock(B) secure part (16) to parts (13,15) ,and using cam lock (C) secure part(16) to part (14)with Philips head screwdriver as per diagram.

Step 19




Place sticker (Q) cover the holes as per diagram .

Step 20




Insert the assembled drawers into the unit frame, extend the Ball Bearing Slide Tracks (X) on the pedestal Side Panel all the way forward .Then align the Slide Runners on the assembled drawers with the Slide Tracks and push the drawer carefully inside until it stops. Note : if the drawer does not go in smoothly, please take it out and repeat the step. If you need to remove the drawer, please pull the drawer all the way out, press or lift the plastic release lever and pull out the drawer and then re-assembled the drawer until it was going in smoothly .

Step 21




Insert shelf support pin (N) into parts (4,5,6) as per diagram. Make sure you place the four shelf support pins (N) in the same level. So the shelf is not titled .Put parts (2,3) into unit as per diagram. Tilt and rest the adjustable shelves(2,3) onto the shelf support pins .

Step 22




Using screw (L) attach handle (K) to parts (7,8), and using screw (J) attach Europe hinge(H) to parts(7,8) with Philips head screwdriver as per diagram.

Step 23





using screw (J) attach Europe hinge(H) to part (4) with Philips head screwdriver as per diagram.

Step 24





using screw (J) attach Europe hinge(H) to part (6) with Philips head screwdriver as per diagram. Open and close the doors ,if necessary adjust the screws for a good fit.

Step 25



Position the assembled unit at the desired location ,if necessary adjust the floor leveler at the bottom of the legs to level the unit .


Step 26



Using screw (T) attach Velcro strap (V) into part (1) with Philips head screwdriver as per diagram.


Step 27

WARNING




Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Wall



Using screw (U) attach Velcro strap (V) into Nut (W) to wall with Philips head screwdriver as per diagram.

Step 28



Final Assembly