


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY

DIFFICULT

Tools Required For Assembly:

Allen Wrench

(Included)

Phillips Screwdriver

(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.











FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.











Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.

Parts List

	#1 x 1pc Back Panel
	#2 x 1pc Front Panel
	#3 x 1pc Left Side Panel
	#4 x 1pc Right Side Panel
	#5 x 1pc Bottom Panel
	#6 x 1pc Top Panel
	#7 x 2pcs Metal Side Frame
	#8 x 2pcs Top Stretcher

Hardware List


	#A x 18pcs Cam bolts
	#B x 18pcs Cam lock
	#C x 1pc Left Support
	#D x 1pc Right Support
	#E x 8pcs Screw 1/8"x1/2"
	#F x 2pcs Hinge
	#Gx 16pcs Screw 1/8"x5/8"
	#H x 2pcs Handle



Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.

Parts List




#9 x 1pc
Bottom Stretcher


Hardware List




#I x 4pcs
Bolt 5/32"x1/2"




#J x 10pcs
Adhesive Pad




#K x 10pcs
Bolt 1/4"x2"



#L x 10pcs
Flat Washer



#M x 1pc
Allen Wrench M4




#N x 6pcs
Bolt 1/4"x3/4"




#A x 4pcs
#B x 4pcs

- I. Screw 4 cam bolts (#A) into the left side panel (#3) and the right side panel (#4) using a Phillips screwdriver.
- II. Insert the other end of the cam bolts (#A) into the bottom panel (#5).
- III. Insert cam locks (#B) into the pre-drilled holes on the bottom panel (#5) and lock using a Phillips screwdriver.



#A x 7pcs
#B x 7pcs
#J x 7pcs

- I. Screw 7 cam bolts (#A) into the back panel (#1) using a Phillips screwdriver.
- II. Insert the other end of the cam bolts (#A) into the left side panel (#3), the right side panel (#4) and the bottom panel (#5).
- III. Insert 7 cam locks (#B) into the pre-drilled holes and lock using a Phillips screwdriver.
- IV. Apply adhesive pads.






#3

#A x 7pcs
#B x 7pcs
#J x 7pcs


- I. Screw 7 cam bolts (#A) into the front panel (#2) using a Phillips screwdriver.
- II. Insert the other end of the cam bolts (#A) into the left side panel (#3), the right side panel (#4) and the bottom panel (#5).
- III. Insert 7 cam locks (#B) into the pre-drilled holes and lock using a Phillips screwdriver.
- IV. Apply adhesive pads.



#4

#N x 6pcs


- I. Insert the top stretchers (#8) and bottom stretcher (#9) into the designated slots located on the metal side frames (#7).
- II. Insert bolt (#N) and secure using the Allen wrench (#M).






#K x 10pcs
#L x 10pcs

- I. Align the bottom assembly to the bottom panel (#5).
- II. Insert flat washer (#L) onto the bolt (#K) then secure using the Allen wrench (#M).



#F x 2pcs
#G x 8pcs



Align the hinges (#F) to the pre-drilled holes located on the back panel (#1) and top panel (#6) insert screw (#G). Secure using a Phillips screwdriver.





#E x 8pcs
#H x 2pcs
#I x 4pcs
#J x 2pcs

- I. Align the left support (#C) and right support (#D) to the corners and insert screw (#E).
Secure using a Phillips screwdriver.
- II. Align handle (#H) to the pre-drilled holes along the sides and insert the bolts (#I).
Secure using a Phillips screwdriver.
- III. Apply the adhesive pads (#J) on the front corners.



ASSEMBLY IS COMPLETED